3M Occupational Health & Environmental Safety Group



3M[™] 6000 Series Half Mask **Care and Maintenance**

To maintain protection levels, optimise the effective lifetime of the equipment and avoid the additional cost of replacement, it is extremely important to carry out regular checks and maintenance on Reusable Respirators.

Before Use

- Inspect respirator for incorrectly fitted and/or damaged parts. Replace if necessary
- Inspect the exhalation valve and seat.

Monthly

- Carry out all the 'Before Use' inspections
- Check:

Face Seal

Straps and Head harness

Valves

· Create record of this monthly check

After Use

- Cleaning is recommended after each use
- Remove the gas/vapour and/or particulate filters
- Clean with 3M[™] 105 wipe or by immersing in warm cleaning solution, water temperature not to exceed 50°C and scrub with a soft brush until clean
- Rinse in fresh warm water
- Air dry in a non-contaminated atmosphere

Ordering Consumables, Repair Parts and Accessories

To request a quote or place an order for these items, please contact your 3M Approved Distributor.

Further Information and Advice

If you require additional guidance on the Care and Maintenance of your 3M[™] Reusable Respirators, please contact the Helpline or your local 3M representative.



Occupational Health & Environmental Safety Group

3M United Kingdom plc 3M Centre, Cain Road, Bracknell Berkshire RG12 8HT Tel: 0870 60 800 60 www.3M.co.uk/ohes

3M Ireland Limited The Iveagh Building The Park Carrickmines Dublin 18 Tel: 1 800 320 500

3M is a trademark of 3M Company Please recycle. Printed in UK. © 3M 2010. All rights reserved.

REPLACE ALL DAMAGED PARTS IMMEDIATELY TO ENSURE CORRECT LEVELS OF PROTECTION



CH6000HMCM Iss.2

