## 3M<sup>™</sup> 8822 Dust/Mist Respirator (Valved) Fitting Instructions



Cup the respirator in your hand with the nosepiece at your fingertips allowing the headbands to hang freely below your hand.



Pull the bottom strap over your head and position it around the neck below the ears.



Place the fingertips of both hands at the top of the metal nosepiece. Mould the nosepiece to the shape of your nose by pushing inward while moving your fingertips down both sides of the nosepiece. Pinching the nosepiece using one hand may result in less effective respirator performance.

Position the respirator

under your chin with

Pull the top strap over

high at the top back of

your head resting it

the nosepiece up.

your head.

The seal of the respirator on the face should be fit-checked prior to wearing in the work area.

a) Cover the front of the respirator with both hands, being careful not to disturb the position of the respirator.

b) Inhale sharply. A negative pressure should be felt inside the respirator. If any leakage is detected, adjust position of respirator and/or tension of strap. Retest the seal. Repeat the procedure until the respirator is sealed properly.

If you cannot achieve a proper fit, do not enter the contaminated area. See your supervisor.

Note - do not use with beards or other facial hair that may inhibit contact between the face and the edge of the respirator.



## 3M<sup>™</sup> 8822 Dust/Mist Respirator (valved)



Standard: EN149 Type: FFP2 Maximum Use Concentrations 10 x WEL\* for Particulates Approval: CE marked

\*Workplace Exposure Limit

Dangerous to Life and Health (IDLH)

5

3M 8822 Dust/ Mist Respirator (Valved)

This respirator should not be used in oxygen deficient environments, for escape purposes or by people with beards/ facial hair or in atmospheres where concentrations of contaminant may exceed that deemed Immediately

